SAMSUNG WISENET



Set-up Guide

3

Pre-set up Check List

Before you set up the camera, make sure to:

- ✓ Have your SmartCam and power adapter ready
- Have your smartphone or tablet ready to download the Wisenet SmartCam+ app
- ✓ Be within range of the same Wi-Fi network you'll use for the camera set-up
- ✓ Have your Wi-Fi network password handy
- Check the system requirements located on the back of the packaging

For more information on your product, please download the user manual from wisenetlife.com.

Need Help?


Contact our Technical Support Team:

Phone: 844 - WISENET (844-947-3638)

Email: cs@samsungsv.com

Open 7 days a week, 9AM - 9PM EST

Product Views for Set up



- 1. MicroSD Card Slot
- 2. Microphone
- 3. Status LED

- Speakers
- 5. Wi-Fi Direct Button
- 6. Reset Button

LED Status Guide

Booting up

Booting completed

Enabling Wi-Fi Direct

Searching for available Wi-Fi network

Connecting to Wi-Fi network

Connected to Wi-Fi network

Updating firmware

Download & Install App

1





Go to the App Store or Play Store on your iOS or Android device.

2



Search for "Wisenet SmartCam+"; install and then open the app.

Create User Account

1



Tap "Create account".

2



Enter in the information requested and tap "Create account".

3



Tap on "OK" once you have successfully registered. You will then be directed to the product setup.

SmartCam App Setup

1



Connect the power to the camera.

2



Wait for the blinking red light and tap "Ready".

3



Press down on the Wi-Fi button until LED light turns yellow.

4 (iOS device only)



Press the home button and access the Wi-Fi Settings. Turn on Wi-Fi and select the last 4 digits of the product's serial#. Enter "smartcam" for the password.

4 (Android device only)



Select the camera's last 4 digit of the product's serial #.

5



Select your home Wi-Fi network and enter the password.

6



Create a name and password for the camera.

7



Congratulation! You've completed the setup and can now access your camera's feed.

Download & Install App







SD Save

Live video is saved to the Micro SD card.





Capture

Saves images captured from a live video.





Previous Stage

After terminating the live connection, you are returned to the main screen.





Two-Way Talk

The microphone is activated to support Two-Way Talk function between the product and smartphone.









Schadular

System Security Status Indicator

Indicates security status for each of the cameras.





Select Video Quality

Shows the quality of the currently connected video. Press it to change the level from high/medium/low.





Video Recording

Recording video to app.





Siren

Play alarm sounds.

Basic Features Guide

Refer to the steps below for quick access to the main features of the app.

Motion Detection

- 1. Go to the app home screen and locate Camera Setting 🔅 -> Event 🗅
- 2. Tap the toggle switch to turn ON/OFF Motion Detection.
- 3. Adjust sensitivity level when Motion Detection is ON.



Motion Zone Select

- 1. Follow steps 1 & 2 as listed above.
- 2. Select Motion Zone.
- 3. Draw boxes in areas of interest within the camera's view (Select up to 3 areas of interest).
- 4. Press Apply when done.





Audio Detection

- 1. Go to the app home screen and locate Camera Setting 🔆 -> Event 🗅
- 2. Tap the toggle switch to turn ON/OFF Audio Detection.
- 3. Adjust sensitivity level when Audio Detection is ON.



Night Vision

- 1. Go to the app home screen and locate Camera Setting 🔆 -> Video 🗊
- 2. Select the Night Vision icon with in the bottom navigation bar to turn on Night Vision.



Basic Features Guide

Video Event Playback

- 1. Go to the app home screen.
- 2. Tap on "Event List" to view videos based on events or "Playback" for continuous and event recordings.
- 3. You can select a date and time to playback specific events.



Event Playback only works if a micro SD card is in the camera.





