


OUTDOOR GAZEBO
ITM./ART. 966731
MODEL#L-GZ682PCO-I
ASSEMBLY INSTRUCTIONS




IMPORTANT: RETAIN FOR FUTURE REFERENCE. READ CAREFULLY.

Please check with your local governing authority / local municipal codes regarding installation of structures before assembly.

Tools required (not included): Phillips screwdriver, hammer, 2 ladders that are at least 8.2 ft / 2.4 m in height, cordless drill, socket, ratchet set (Metric), socket adapter and socket driver, carpenter's level.















WARNING:















- Check to ensure all parts are present prior to assembly.
- This unit is heavy! **5 adults are needed for safe assembly ---- Never assemble this alone!** 
- Keep all children and pets away from assembly area. Children and pets should be supervised when they are in the area of the gazebo construction.
- Keep assembly area more than 6 ft / 1.8 m from any obstruction such as fence, garage, and house, overhanging branches, laundry line or electrical wires.
- Some parts may contain sharp edges. When assembling and using this product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to the product. Please read all instructions before assembly and use.
- For outdoor use only. Check all bolts for tightness before use and periodically check and tighten bolts as necessary.
- Assemble this unit on firm, level ground or hard surface only. Ensure the unit is level after final assembly.
- Protect parts during assembly by laying them on a non-abrasive surface such as blankets or cardboard.

IMPORTANT









Please do not return this product to the store. For technical assistance or replacement parts call Sunjoy from 8:30 AM to 5:30 PM Eastern Time at the following: 1-866-578-0101 (English, French & Spanish in US) or e-mail: service@ferro-works.com.

Parts List


PART #	DESCRIPTION	QTY	LINE DRAWING OF PART
A1	Gutter 1 (Long)	2	
A2	Gutter 2 (Short)	6	
A3	Corner Cover 1 (Outside)	8	
B1	Post 1	2	
B2	Post 2	2	
B3	Post 3	4	
C	Fence	2	
D	Slate Top	2	
E1	Bracket (Slate Top)	4	
E2	Connector 1 (Slate Top)	2	
F	Bar 1 (Large Roof)	8	
G1	Roof Panel 1 (Large Roof, Long & Upper)	2	
G2	Roof Panel 2 (Large Roof, Long & Lower)	2	
G3	Roof panel 3 (Large Roof, Short & Upper)	6	

PART #	DESCRIPTION	QTY	LINE DRAWING OF PART
G4	Roof Panel 4 (Large Roof, Short & Lower)	6	
H	Connector 2 (Slanting Bar)	8	
I	Bar Cover (Large Roof)	8	
J1	Lock Plate 1	16	
J2	Lock Plate 2	16	
K1	Roof Frame (Large Roof)	1	
L	Bar 2 (Small Roof)	8	
M1	Roof Panel 5 (Small Roof, Long)	2	
M2	Roof Panel 6 (Small Roof, Short)	6	
N	Connector 3 (Small Roof)	1	
O	Hook	1	
P	Bar Cover (Small Roof)	8	
Q	Corner Cover 2 (Inside)	8	
R	Connector Cover (Small Roof)	1	

Hardware Packet for Step 1

PART #	DESCRIPTION	QTY	LINE DRAWING
AA	M6 x 15mm bolt	16	
BB	M6 washer	152	
CC	M6 x20mm bolt	48	
DD	M6 x 35mm bolt	32	
EE	M6 x 55mm bolt	16	
FF	M6 x 65mm bolt	16	
GG	M6 nut	24	
Z	M6 wrench	2	

Step. 1








Fig.1: Attach Connector 2 (H) to Post (B1, B2, B3) with bolt (EE), washer (BB) and nut (GG). Do not tighten them at this step.
Fig.2: Attach Gutter (A2) to Post (B1, B2) with bolts (CC, DD) and washer (BB), fix Connector 2 (H) with Gutter (A2) with bolts (CC, DD) and washer (BB). Do not tighten them at this step.






Fig.3: Attach Fence (C) to Post (B1, B2) with bolt (EE) and washer (BB). Make sure screw holes in Fence (C) are facing out and at the top.

Fig.4: Attach Gutter (A1) to Post (B3) with bolt (CC) and washer (BB) and fix Connector 2 (H) with Gutter (A1) with bolt (DD)






Fig.5: Attach Gutter (A2) to Post (B3) with bolt (CC) and washer (BB) and fix Connector 2 (H) with Gutter (A2) with bolt (DD) and washer (BB). Do not tighten them at this step.

Fig.5-1: Attach Gutter (A2) to Post (B2) with bolt (CC) and washer (BB) and fix Connector 2 (H) with Gutter (A2) with bolt (DD) and washer (BB). Fasten all the bolts and washers including those that are not fastened at the steps above. Once all of the gutters are installed, adjust the alignment of the gutters to the posts so that each post and gutter are equal distance apart and that each post is plumb and vertically aligned with the gutters.






Fig.6: Attach Bar 1 (F) to Connector 2 (H) with bolt (FF), nut (GG) and washer (BB).

Fig.7: Attach Bar 1(F) to Roof Frame (K1) with bolt (AA) and washer (BB)

Hardware Packet for Step 2

PART #	DESCRIPTION	QTY	LINE DRAWING
AA	M6 x 15mm bolt	8	
BB	M6 washer	24	
FF	M6 x65mm bolt	8	
GG	M6 nut	8	

Step. 2






Fig.8: Secure Bar 2 (L) and Roof Frame (K1) with bolt (AA) and washer (BB).




Fig.9: Screw Hook (O) upon Connector 3 (N).





Fig.10: Attach Bar 2 (L) to Connector 3 (N) with bolt (FF), nut (GG) and washer (BB) and fasten them.

Hardware Packet for Step 3

PART #	DESCRIPTION	QTY	LINE DRAWING
AA	M6 x 15mm bolt	16	
BB	M6 washer	178	
CC	M6 x20mm bolt	2	
OO	M6 x 45mm bolt	16	
HH	M6 x 15mm bolt	128	
II	M6 x 25mm bolt	16	

Step. 3








Fig.11: Place Roof Panel 5 (M1) and Roof Panel 6 (M2) on Bar 2 (L) and secure them with bolt (HH) and washer (BB).

Fig.12: Place Bar Cover (P) between the assembled roof panels and secure them on Bar 2 (L) with bolt (OO) and washer (BB).

Fig.13: Place Connector Cover (R) on Bar Cover (P) between and fasten them with bolt (CC) and washer (BB).






Fig.14: Place Roof Panel 1 (G1) and Roof Panel 3 (G3) on the upper end of Bar 1 (F) and secure them with bolt (AA) and washer (BB), bolt (HH) and washer (BB).

Fig.15: Place Roof Panel 2 (G2) and Roof Panel 4 (G4) on the lower end of Bar 1 (F) and secure them with bolt (HH) and washer (BB).

Fig.16: Secure Roof Panel 2 (G2) and Roof Panel 4 (G4) on Connector 2 (H).






Fig.17: Attach Corner Cover 1 (A3) to the assembled Gutter (A1, A2) with bolt (II) and washer (BB). Adjust the Corner Cover by holding the cover in place to align with the gutters and tightening the bolts. You can make additional adjustments by loosening the bolts that are attached to the gutters at the post tops (see Fig.4).


Fig.18: Put Bar Cover (I) between these large roof panels and secure them with bolt (HH) and washer (BB).

Fig.19: Attach Corner Cover 2 (Q) to the assembled Gutter (A1, A2) with bolt (HH) and washer (BB).

Hardware Packet for Step 4

PART #	DESCRIPTION	QTY	LINE DRAWING
AA	M6 x 15mm bolt	20	
BB	M6 washer	20	
MM	8 x 260mm stake	16	
JJ	M10 x 70mm expansion bolt	16	

Step. 4






Fig. 20




Fig. 21

Fig.20: Attach Bracket (E1) to Fence (C) with bolt (AA) and washer (BB).

Fig.21: Attach Connector 1 (E2) to Slate Top (D) and Fence (C) respectively with bolt (AA) and washer (BB).




Fig. 22




Fig. 23

Fig.22: Secure all Posts (B1, B2, B3) to the ground with stake (MM) if it is soft surface.

Fig.23: Secure all Posts (B1, B2, B3) with expansion bolt (JJ) if installed on a concrete base.

CARE INSTRUCTIONS

Clean gently with a sponge using environmentally-friendly soap solution and water. Do not use abrasive materials, wire brushes, chemicals, cleansers or bleach. Do not use a pressure washer. Rinse well. Allow to air dry.

If there are nicks, chips or scratches, go to your local hardware store or home center and obtain a closest match touch-up paint suitable for outdoor metal use. Follow instructions that appear on the paint can.

SPECIFICATIONS:

Resiste vientos de hasta 50 mph when firmly anchored using stakes to the ground.

Resiste vientos de hasta 63 mph when firmly anchored using expansion bolts into a suitable concrete base.

Roof can withstand up to 550 lbs / 249 kg weight load.

Maximum load for the center hook: 88 lbs / 39.9 kg.

MADE IN CHINA